

Fog Lamp Instructions

2010-2014 Jeep Wrangler

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance feel free to call us at: 1-800-247-3974

Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

Table 1.0

KIT CONTENTS:	
Description	Qty.
4" Round Puck with Wiring Harness	2
Mounting Bracket with Plastic Caps	2
10-32 X 3/8" Machine Screw	4
#10 Lock Washers	4

Tools Needed:


- 18mm Socket
- Ratchet Wrench
- Phillips screwdriver
- Plastic pry bar or flat bladed screwdriver

Before Installation Verify that all contents listed are included in your kit

Fog Lamp Removal

Note: The installation of this product requires removal of the front bumper

1. Remove plastic skid plate cover between radiator support and bumper. Use a plastic pry bar or flat bladed screwdriver to remove all six plastic rivets attaching it to the vehicle. Refer to Figure 1



2. Remove eight bolts that attach the bumper to the vehicle with an 18mm socket and ratchet wrench. Refer to Figure 2 for outer and inner bolt locations.



LIMITED 2 YEAR WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.

3. Remove the 4 clamping plates and disconnect the wiring harness before pulling off the bumper.
4. With the bumper removed unscrew the four Phillips screws that hold each fog lamp bracket to the bumper.
5. Remove fog lamp assembly and set aside for next step as some parts are reused.

Fog Lamp Assembly

6. Remove Putco fog lamps from packaging. Check to see if all parts from Table 1.0 are included.
7. Place Mounting brackets on back side of fog lamps matching the holes and the curved outer profile.
8. Tighten the screws with a Phillips screwdriver until tight. **Note: Start screws by hand to avoid cross threading.**
9. Disassemble original fog lamps from housing. The mounting bracket and adjusting screw are reused with the kit. Refer to Figure 3 for the highlighted parts that get reused.
10. Install adjuster screw assembly so that it faces the wiring harness side of the fog lamp. Refer to Figure 3.
11. Thread wiring harness through center of plastic mounting bracket. Orient fog lamp so that the adjusting screw is on the correct side of the plastic mounting bracket.
12. Squeeze top and bottom of plastic mounting bracket to expand enough to clip fog lamp and mounting bracket together.
13. Loosen adjusting screw if necessary to place the screw head into its original location on the plastic mounting bracket.



LIMITED 2 YEAR WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.

Fog Lamp Installation

1. Place fog lamps in bumper, oriented with the adjuster screw pointed towards the bottom of the bumper.
2. Screw the fog lamps into the bumper using the existing screws.
3. Bolt the bumper to the vehicle in the reverse order it was taken off.
4. Connect the factory wiring harness to the fog lamp harness. Ensure that the connectors are fully engaged and snaps together without pulling off.
5. Test that the fog lamps turn on and off properly.
6. Adjust the fog lamps with a Phillips screwdriver so that they shine at the desired angle. Refer to Figure 4.



7. Reinstall the plastic skid plate in reverse order of its removal.

LIMITED 2 YEAR WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.