

0

For proper installation and best possible fit, please read all instructions BEFORE you begin.

Important Information

BEFORE you begin the installation process:

- Carefully read all instructions.
- Verify that all parts are included by checking the contents of your kit.

If any parts are missing or appear damaged, please contact our customer service team for assistance.

Customer Service

For support, please contact the Putco team, available Monday to Friday 8:30 AM to 5PM (Central Time).

1 800 247 3974

support@putco.com

Supported Vehicles			
MAKE	MODEL	YEAR	
Hyundai	Santa Cruz	2021	

Recommended Tools + Supp	lies
3/16" Allen Wrench	Utility knife

Kit Contents		
2 x Rail End Cap	2 x Bed Rail	4 x 5/16"-18 screws
4 x Plastic Gaskets	4 x Metal Clamps	4 x Plastic Insert
4 x Rubber Bands		

Step by Step Installation

 Using a utility knife, cut out stake pockets from the bed caps.



2. Using the metal clamp, plastic insert, and a rubber band, begin assembling the bracket clamps.

> Note: This will be repeated three times.





3. Assemble the rail. When screwing the bracket clamps to each end, only tighten to the point where the screw is flush with the bracket clamp.

ease of installation, align the clamps so the longer ends face the same direction.

4. Insert the brackets into the stake pocket at the same time. Make sure the longer side of the bracket is inserted first with it going towards the outside of the vehicle.





<pre>5. Use a 3/16" Allen wrench to tighten the rail to the bed. Note: For ease of installation, lift up on the rail for tension as you tighten</pre>	
6. Repeat process for opposing side.	

Congratulations on completing the installation of your Putco product! For information regarding your warranty, please visit <u>www.putco.com/warranty</u>.

Issues? Please Contact Our Technical Support Team: 1 800 247 3974

WARNING: Final Inspection required. Inspect product was properly Installed and all installation instructions were followed.



A

For additional information, please visit our website at www.putco.com!