



For proper installation and best possible fit, please read all instructions BEFORE you begin.

Important Information

BEFORE you begin the installation process:

- Carefully read all instructions.
- Verify that all parts are included by checking the contents of your kit.

If any parts are missing or appear damaged, please contact our customer service team for assistance.

Customer Service

For support, please contact the Putco team, available Monday to Friday 8:30 AM to 5PM (Central Time).

1 800 247 3974

support@putco.com

Supported Vehicles

MAKE	MODEL	YEAR
Ford	Bronco	2021+

Recommended Tools + Supplies

T40 Torx Key	
--------------	--

Kit Contents

Bronco Single Hoop		
--------------------	--	--

Step by Step Installation

1. Begin by loosening the bolts as seen in the figure



2. Place the single hoop onto the bumper



3. Insert the bolts removed in step one and tighten



4. Ensure all bolts
are fastened



Congratulations on completing the installation of your Putco product!
For information regarding your warranty, please visit
www.putco.com/warranty.

Issues? Please Contact Our Technical Support Team: 1 800 247
3974



WARNING: Final Inspection required. Inspect product was properly Installed and all
installation instructions were followed.



For additional information, please visit
our website at www.putco.com!